




SKU # 1000 050 191  
YOW SKU # 693 319  
Model # TY495-1514

## USE AND CARE GUIDE

### 5 ft Lighted Tinsel Soldier



THANK YOU

We appreciate the trust and confidence you have placed in Home Accents through the purchase of this 5 ft Lighted Tinsel Soldier. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Accents!

#### Guarantee

##### What is Covered

The product is intended for residential seasonal use for approximately 90 days per year. This product is covered by a 90 day limited guarantee due to defects in material and workmanship. Return the product with purchase receipt to the location of purchase for refund within 90 days of purchase.

##### What is Not Covered

This warranty does not cover commercial use, normal wear and tear, products not used in accordance with directions provided on or with the product, burn out of bulbs or LEDs, batteries, products that have been subjected to unauthorized repair and/or modification and damage caused by shipping and improper handling, alterations, misuse or accidents. Questions, problems, missing parts? Before returning to the store, call Home Accents Holiday Customer Service 8 a.m.-6 p.m., EST, Monday-Friday

1-877-527-0313


HOMEACCENTSHOLIDAY.COM

## Pre-Assembly

### PLANNING ASSEMBLY

Carefully remove all the parts from the box and place them on a flat surface. Read the entire manual prior to assembly and identify all the parts included in the package against the parts list. If any parts are missing or damaged do not attempt assembly. Contact our customer service center or return to store. Assembly of this product may require more than one person.

### PACKAGE CONTENTS



Package Contents/Parts List		
Part	Description	Quantity
A	Top of Scepter	1
B	Scepter Pole Sections	2
C	Head with Hat	1
D	Halves of Body	2
E	Ear	2
F	Arms	2

Package Contents/Parts List		
Part	Description	Quantity
G	Legs/Feet	2
H	Round Base Stand	1
I	Crown	1
J	Ground Stakes	4
K	Spare Fuse	2
L	Spare Bulb	6
M	Plastic Ties	10

## Assembly

### Assembling the Tinsel Soldier




FIG.1




FIG.2

Step 1. Align the two Halves of Body (D) with each other and insert the rods on one half into the holes on the other half then fasten them together with the Plastic Ties (M) using the metal loops on the frame. (FIG.1)

Step 2. Insert the two posts at the bottom of each Leg/Feet (G) into the matching holes in the Round Base Stand (H). Insert the rods at the bottom of the Body into the matching holes on the top of the Legs. (FIG.2)




FIG.3




FIG.4




FIG.5

Step 3. Insert the rods of the Head (C) into the matching holes on the Body. Attach the Crown (I) to the Head. Hook each Arm (F) onto the Body. Secure with Plastic Ties. (FIG.3)

Step 4. Insert the rods of the Ear (E) into the matching holes on the Head. Insert the Bottom Part of the Scepter Pole Section (B) into the stem protruding from the Round Base Stand. Note: Make sure the end with coupling is up. (FIG.4)

Step 5. Stack the remaining Scepter Pole Section into the top of the Bottom Part of Scepter Pole Section. Note: Feed the Pole downwards thru the hole in the right hand. Stack the Top of Scepter into the top of the Scepter Pole Section. (FIG.4,5)

Step 6. Secure the Soldier to the ground with the Ground Stakes (J). (FIG.5)

## Pre-Operation

**CAUTION:** Grasp the plug to insert or remove from the power source. Do not unplug by pulling on cord.

**CAUTION:** The lighting string on this product is rated at 81.6 Watts (0.68 Amps). Do not overload. Do not connect to other lighting strings, decorative outfit or other electrical products. Before you use or re-use this product inspect it carefully. Return to Store or discard if the product has cuts, damage or frayed wire insulation on cords, cracks in the socket enclosures, loose connections or exposed copper wire.

## Care and Cleaning

- Carefully remove the product from wherever it is placed. This helps to avoid any undue strain or stress on the product, wire and lighting connections. If the product is placed somewhere other than the ground it should be well secured and stable.
- Wipe the unit with a damp cloth and allow the unit to dry before storing.
- Store the product neatly in a cool, dry location protected from sunlight.

## FOR INDOOR AND OUTDOOR USE